PASS Quick Reference Guide

TO ARM ENTIRE SYSTEM-BOTH INTERIOR AND PERIMETER:

- ◆ Close all windows and doors (the green READY light will turn ON)
- ◆ Press and hold (AWAY) for 2 seconds (the keypad will beep rapidly 5 times and the red ARMED light will turn ON) RESIDENTIAL ONLY
- ◆ Exit Premises before the delay time expires

TO DISARM SYSTEM WHEN YOU RETURN:

- ◆ When you enter through the door, the keypad will emit a steady warning tone
- ◆ Enter your 4-digit Master Code or User Code (the armed light will turn OFF)
- ◆ If you enter an incorrect code press # and enter the 4-digit code again

TO EXIT WITHOUT DISARMING THE SYSTEM:

- ◆ Press and hold (EXIT) for 2 seconds
- ◆ After you have exited the building the system will return to the previously armed state

TO ARM PERIMETER OF BUILDING AND STILL MOVE FREELY INSIDE (RESIDENTIAL ONLY):

◆ Press and hold (STAY) for 2 seconds

TO ARM SYSTEM WITH DOOR OR WINDOW OPEN:

- ◆ Press * 1 while disarmed
- ◆ The **BYPASS** light will flash
- ◆ Enter the 2-digit zone number to be bypassed
- ◆ To exit the Bypass function press #

TO SILENCE ALARM:

◆ Enter your 4-digit Master Code or User Code

TO CANCEL AN ALARM CALL:

IL: 618-394-1144

MO: 314-241-0422

Toll Free: 866-490-7277

*Press 1 to be connected to Central Station

WHEN TROUBLE LIGHT COMES ON:

- ◆ Press * 2
- ◆ Some keypads will describe the Trouble (full-message keypads); others will only identify the Trouble Number (fixed-message and LED keypads)
- ◆ If Trouble Number 8 is lit, the time and date needs to be reset
- ◆ For all other trouble conditions, contact PASS
 Security Customer Service

TO SET TIME AND DATE:

- ◆ Press *** 6** and enter the 4-digit Master Code
- ◆ 1 long beep indicates an error, press # and enter the Master Code again
- ◆ After 4 short beeps, press 1 then 10 digits, 2 each for the hour, minute, month, day, and year (HH:MM MM/DD/YY)
 - Use a 24-hour clock (e.g. 8:30 pm = 20:30)
 - ❖ Use 2 digits each to indicate the month and day (e.g. March 8 = 03 08)
 - ♦ Only enter the last 2 digits of any given year (e.g. 2007 = 07)

TO ENABLE DOOR CHIME FEATURE:

- ◆ Press and hold (DOOR CHIME) for 2 seconds
- \bullet 3 beeps = ON; 1 long beep = OFF

TO SOUND AN ALARM MANUALLY:

- ◆ Press and hold **(FIRE)** for 2 seconds. The fire key causes an audible alarm, Fire Department will be dispatched. This alarm may not be cancelled.
- ◆ Press and hold (TRIANGLE/!) for 2 seconds. The ! key causes a silent alarm, Police Department will be dispatched. This alarm may not be cancelled.
- ◆ Press and hold **(POLICE)** for 2 seconds. The POLICE key causes an audible alarm, Police Department will be dispatched. This alarm may not be cancelled.

Don't Forget to Ask About Our Service and Inspection Packages!



